

TECHNICAL INFORMATION

Cooking appliances

4-033-1708

INSTRUCTIONS FOR CONNECTION OF NEW ENERGY SWITCH/ENERGY REGULATOR

When you order a energy switch/energy regulator 546348, you get a little bit different(it is used since 06/2017) energy swithc/energy regulator. Connect as follows:

1. All markings of contacts on old and new energy switch/energy regulator is the same (S1, S2, P1, P2, 2, 4,..). The difference is just in position of connections.



2. Makes just a transitions from old to new energy switch/energy regulator. Watch picture below:

